


# OWNERS MANUAL

## GUITAR AMPLIFIER

MG-10R / MG-10  
SG-10R / SG-10



1. Input - Connection of instrument.
2. Drive - This controls the amplifier overdrive.
3. Overdrive on/off switch - This is used to switch overdrive on/off.
4. Level - This controls the clean level and output level.
5. Treble - Provides high frequency equalization as required.
6. Bass - Provides bass frequency equalization as required.
7. Level - This controls the amount of reverb applied to the output signal.
8. TAPE/CD - This is a TAPE/CD input terminal for connecting your TAPE or CD.  
This is used stereo phone plug.
9. Phones - Used to connect stereo headphones.
10. Power LED - Illuminated when power is On.
11. Power switch - Turns amplifier ON and OFF

**CAUTION!** TO REDUCE THE RISK OF FIRE,  
REPLACE ONLY WITH SAME TYPE FUSE.

**WARNING!** TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK,  
DO NOT EXPOSE THIS EQUIPMENT TO RAIN OR MOISTURE.

**WARNING!** This amplifier must be earth grounded.

### Technical Specifications

<b>RATED POWER</b>	10Watts RMS THD 5% 8ohm Load
<b>FREQUENCY RESPONSE</b>	40Hz to 8KHz
<b>INPUT SENSITIVITY</b>	26mV
<b>S/N RATIO</b>	-45dB
<b>POWER CONSUMPTION</b>	26Watts max
<b>DIMENSIONS(W X H X D)</b>	318 x 334 x 248 mm
<b>WEIGHT</b>	6 Kg